

To accompany extension brackets part no's 7180, 7185



**CYCLE RACKS**

## **150mm/250mm EXTENSION BRACKET**

**PART NO's 7180, 7185**

### **IMPORTANT NOTES:**

**THIS BRACKET MUST NOT BE USED IN CONJUNCTION WITH 4 BIKE  
EZI-GRIP BIKE RACKS.**

**IT IS RECOMMENDED THAT THIS BRACKET ONLY BE FITTED TO TOWBARS  
MANUFACTURED WITH 20mm THICK TONGUES**

### **FITTING INSTRUCTIONS**

Thank you for purchasing this extension bracket to carry your valued bike rack and bicycles. We know you will get many years of use out of the product as it has been well engineered and built from the best material available on the market.

This, combined with the fact that the product has undergone rigorous testing, makes this product one of the best of its type available on the market.

### **MOUNTING EXTENSION BRACKET**

1. Ensure the towball is tight on your towbar.
2. Dab a small amount of grease on the beginning of the threads, this will aid tightening against the towball and lubricate the threads.
3. Insert grub screws into the round nuts on the extension bracket.
4. Place the extension bracket onto the towball and tighten grub screws. It is important to ensure the grub screws are tightly fastened onto the ball. Lightly greasing the threads from time-to-time, between using your rack, will make this easier.
5. NOTE: This bracket must be horizontal at all times.
6. Rock the bracket while pushing on the Allen key with your foot to ensure it is seated correctly, taking care not to bend the Allen key.
7. Ensure the towball on the extension bracket is tight.

You are now ready to install your Ezi-Grip bike rack onto the extension bracket. Refer to the separate instructions provided with your riser tube and hanger tube assembly

**NOTE; THE RISER TUBE MUST BE VERTICAL WHEN FITTED TO THE EXTENSION BRACKET.**

To accompany extension brackets part no's 7180, 7185

## **!!! IMPORTANT SAFETY INFORMATION !!!**

- 1. DO NOT USE THE 4 BIKE EZI-GRIP BIKE RACK ON THIS EXTENSION BRACKET.**
- 2. CAUTION SHOULD BE TAKEN IF THIS EXTENSION BRACKET IS FITTED TO TOWBARS WITH TONGUE MATERIAL THICKNESS LESS THAN 20mm.**
- 3. WE RECOMMEND THE USE OF A SUPPORT STRAP Part No. 7149 WITH ALL EXTENSION BRACKETS.**
- 4. DO NOT TOW FROM THIS EXTENSION BRACKET.**  
It must only be used for Ezi-Grip cycle racks.
- 5. DO NOT FIT TO EUROPEAN STYLE "GOOSE NECK" TOWBARS.**  
If you have a European style tow bar either, replace it with a NZ style or purchase a European Style Ezi-Grip II, with a mounting system capable of fitting your European tow bar.
- 6. MAXIMUM TONGUE LOAD 50kg**
- 7. THE TUBE MUST BE VERTICAL AT ALL TIMES.** A flexing, bent towbar or loose rack could cause the riser tube to bend. Use trunk strap Pt No: 7149 if your towbar flexes. The towbar should not flex more than 10mm at its most rearward point. Remember to rock the riser tube while firmly tightening the Allen screw/s. Periodically check tightness of rack